

Locating the logger serial number

For hybrid inverter logger serial number (SN) is located in wifi antenna



For microinverters logger serial number (S/N) is located in MIC frontal

